CLEANING YOUR PAN

- Before the first use, wash the pan in hot, soapy water and then towel it dry.
- Never use abrasive cleansers, bleach, steel wool, scouring pads, or harsh chemical fluids. For occasional dried-on food, simply soak the pan in hot water for a few minutes and then scrub it with a damp sponge or cloth.
- The **Edge Brownie Pan®** is not dishwasher safe. Please handwash the pan to avoid possible damage to the nonstick coating. The pan is super nonstick, so we did half of the job already!


USE & CARE

• Your *Edge Brownie Pan*® is oven-safe to 500 degrees Fahrenheit in a conventional oven. The pan should not be used to cook food on a stovetop burner and never use it in a microwave oven.

• The pan's handles will be very hot when the pan is removed from the oven, so always use oven mitts or a hot pad.

RECOMMENDED UTENSILS

- Only nonstick-safe utensils should be used with your Edge Brownie Pan.® Never use metal or other sharp utensils.
- Scraping the pan or applying heavy pressure could scuff or scratch the coating.



MATT: Baker's Edge started out as dare mixed with a little bit of challenge, and then a whole lotta hard work. Just out of college (in 1998) - my friends and I were talking about simple inventions that seem so obvious, but took years before they were imagined. Shortly after this, while chomping on a warm brownie (a corner piece – my favorite), it suddenly struck me. A simple redesign of the typical square pan could give me a pan full of corners. It was an a-ha moment. I was convinced this was the "new way" to bake brownies – and despite the naysayers and hurdles - it finally hit the store shelves in 2006. Would I do it

again? YES! Would I do things differently? YES! But somehow it all worked out anyway! We are so proud to be "Made in the USA." We never took a bail out, and would never ask – we just keep working hard and figuring things out.

EMILY: As a chef, you may think it was second nature for me to help launch a bakeware brand. Not at all! I know baking – but metal castings, coatings, packaging, logistics – that is not what chefs do! It has been a wild ride, with thankfully more ups than downs. I love that we have kept the company small, personal, and have never backed away from the best quality and service we can deliver. We love defying the odds by being successful, scrappy Midwestern entrepreneurs. We like to think we have some qualities that can never be copied or faked – personality, real people behind our business, and a good number of fresh ideas. We have so much

Read the whole story on the ABOUT page of our website!

www.BakersEdge.com

cool stuff on the horizon – just wait!

OUR LIMITED WARRANTY

Baker's Edge® will promptly replace any Edge Brownie Pan® found to be defective in materials or workmanship under normal use (following the directions and instructions in this insert) for 90 days from the date of purchase. Minor imperfections or scratches, surface markings as a result of shipping, and slight color variations are normal and may also occur with wear. This warranty specifically excludes damage due to improper storage, exposure to extreme temperatures, prolonged exposure to moisture, using metal or other improper utensils, neglect, fire, accident, alteration, theft, or use in a commercial establishment.

Because the pan is not dishwasher safe, this warranty excludes any damage resulting from cleaning the pan in a dishwasher. This warranty also excludes damage attributable to the improper use of utensils, including marks and scratches that may occur with use.

Proof of purchase is required. Therefore, we strongly recommend that you keep your sales receipt, invoice, or credit card bill. If you believe your Baker's Edge® product is defective, please send an email to info@bakersedge.com, or send a letter to us at:



Baker's Edge | Sorfeo Inc 488 E Winchester ST **Suite 150** Murray, UT 84107

We're always eager to hear from our customers and fans. If you'd like to send us comments or suggestions, please contact us via email at info@bakersedge.com or write to us at the postal address above.

IT'S A LID, SILLY!

Use it to keep your goodies fresher longer. It's also high heat resistant – so use it as a cooling pad to protect your surfaces!

WEDGE

You use this WHILE baking. It stays in the pan! This bakeware silicone wedge is used to convert the Edge Brownie Pan® into an 8" x 8" volume baker (think one box mix of brownies or cornbread). This little guy is like getting a free pan! NIFTY!

Lid, Wedge and Spatula are Dishwasher safe, and high heat resistant. Always hand wash your Edge Brownie Pan® (non stick and dishwashers do not mix well!)





The Lid and Wedge are made of high quality bakeware silicone and while designed in the USA, they are manufactured in China. If you have a contact in the USA that can make these – drop us an email at info@bakersedge.com. The Edge Brownie Pan® is still 100% made in the USA.

Marbled Pheesecake Brownies

BROWNIE BASE INGREDIENTS

1 34 cup All Purpose Flour 34 tsp Baking Soda ¾ tsp Salt 12 Tbsp Unsalted Butter, room temp

Bittersweet Chocolate, chopped

1½ cup Sugar 3 ea

Vanilla Extract

INSTRUCTIONS

Preheat oven to 350°F. Lightly spray the pan with non-stick cooking spray.

2 First, make the brownie base. Combine the flour, baking soda and salt in a small bowl. 3 In a medium bowl, sitting over a simmering pot of water (make sure the bottom of the bowl does not touch the water) melt the butter and chocolate, stirring occasionally until melted and then remove from the heat. Stir in the sugar to the chocolate mixture. Stir in one egg at a time followed by the vanilla extract. Stir in the flour mixture.

4 To make the cheesecake filling, combine the cream cheese and butter in a small bowl until smooth and creamy. Stir in the sugar and vanilla extract. Stir in the egg yolks, one at a time. Add the flour and stir to combine.

5. Pour the brownie base into the prepared pan. Pour the cheesecake filling on top of the brownie base. Using a non-stick safe utensil, swirl the cheesecake into the brownie base making sure not to mix the two completely.

6 Bake for 45-50 minutes or until a toothpick inserted into it comes out with moist crumbs. Cool the brownies completely in the pan.

CHEESECAKE FILLING INGREDIENTS

6 oz Cream Cheese, room temp 4 Tbsp Unsalted Butter, room temp

½ cup Sugar

1 tsp Vanilla Extract

3 ea Egg Yolks 14 cup All Purpose Flou





More recipes online at BAKERSEDGE.COM

Raspberry Pecan Blondies

Ingredients

2 cups All Purpose Flour 2 cups Brown Sugar **Baking Powder** 2 ea Eggs Baking Soda 1½ tsp Vanilla Extract ¼ tsp Salt Lemon Zest ½ tsp ½ tsp Nutmeg Pecans, coarsely chopped 12 Tbsp Unsalted Butter, room temp Raspberries

Instructions

- 1 Preheat oven to 350°F. Lightly spray the pan with non-stick cooking spray.
- 2 Combine the flour, baking powder, baking soda, salt & nutmeg in a small bowl.

1 cup

- 3 In a large bowl, beat the butter and the brown sugar with an electric mixer until light and fluffy. Add each of the eggs, one at a time, mixing well after each addition. Then add the vanilla extract and lemon zest. Add the dry ingredients and beat just until combined. Stir in the pecans.
- 4 Spread the dough into the prepared pan. Sprinkle the top of the dough with the raspberries.
- **5** Bake for 40-45 minutes or until the top is golden and a toothpick inserted into it comes out clean. Cool the blondies completely in the pan.



More recipes online at BAKERSEDGE COM